

How To Install Garbage Disposal

How To Install Garbage Disposal

Downloaded from app.ardentx.com by Eaton & Clark

If you’ve ever struggled with a sink full of food scraps or dealt with the unpleasant odor of decomposing leftovers, you already know the value of a garbage disposal. Installing one yourself not only saves you the cost of hiring a plumber but also gives you a sense of accomplishment. With the right tools, a bit of patience, and a clear understanding of the process, you can handle this project in a weekend. This article walks you through everything you need to know about how to install a garbage disposal, from preparation to final testing.

WHY INSTALL A GARBAGE DISPOSAL YOURSELF?

Garbage disposals are essential kitchen appliances that grind food waste into small particles, allowing it to pass safely through plumbing. While professional installation is always an option, doing it yourself can save between \$100 and \$200 in labor costs. Moreover, the process is straightforward for most standard sinks. Whether you’re replacing an old, noisy unit or adding a disposal for the first time, this guide will help you complete the job with confidence.

TOOLS AND MATERIALS YOU WILL NEED

Before starting, gather all necessary tools and materials. Having everything on hand prevents frustrating interruptions and ensures a smooth workflow.

Essential Tools

- Adjustable wrench or channel lock pliers
- Screwdrivers (flathead and Phillips)
- Plumber’s putty
- Bucket or large bowl
- Flashlight
- Utility knife
- Wire strippers (if hardwiring)
- Voltage tester

Materials and Parts

- New garbage disposal unit (check power and size compatibility)
- Mounting assembly (usually included with the disposal)
- Dishwasher drain hose connector (if applicable)
- Electrical cord (if not factory-installed)
- Wire nuts and electrical tape
- PVC pipe fittings (if altering drain lines)
- Teflon tape for threaded connections

SAFETY FIRST: WHAT TO KNOW BEFORE YOU BEGIN

Working under a sink involves electricity and plumbing, so safety is critical. Always start by turning off the power to the disposal circuit at the breaker panel. Use a voltage tester to confirm that no electricity is flowing to the existing disposal or the wiring. If you are working with an existing unit, also shut off the water supply lines and place a bucket under the trap to catch any residual water. Wear gloves and eye protection—old disposal units can be heavy, and debris may fall when disconnecting

pipes.

STEP-BY-STEP GUIDE: HOW TO INSTALL A GARBAGE DISPOSAL

Step 1: Remove the Old Disposal (If Replacing)

If you are replacing an existing garbage disposal, start by disconnecting it. First, unplug the unit or turn off the circuit breaker. Then, use a wrench to loosen the slip nuts connecting the drain pipes. Remove the P-trap and any other pipe sections attached to the disposal. Next, disconnect the dishwasher drain hose if connected. Finally, use a screwdriver or disposal wrench to loosen the mounting ring that secures the disposal to the sink flange. Rotate the disposal counterclockwise to disengage it from the mounting assembly, and carefully lower it into the bucket. If you are installing a brand new disposal where none existed before, you can skip this step and move directly to preparing the sink.

Step 2: Prepare the Sink Opening

Clean the sink flange area thoroughly. Scrape away old plumber’s putty or debris. If your sink has a strainer basket, remove it by unscrewing the locknut underneath. For a new installation, ensure the sink opening is sized correctly for the disposal’s mounting flange (typically 3½ to 4 inches in diameter). If the opening is too large, you may need a mounting adapter or a replacement sink strainer.

Step 3: Install the Mounting Assembly

The mounting assembly consists of a flange, a gasket, and a mounting ring. Roll a rope of plumber’s putty into a thin snake and press it around the underside of the sink flange. Insert the flange into the sink opening from above, pressing firmly to seat it. From below, slide the rubber gasket and then the metal mounting ring over the flange. Tighten the three screws evenly until the flange is snug against the sink. Wipe away any excess putty that oozes out from above. This step is crucial because a loose flange will cause leaks.

Step 4: Connect the Dishwasher Drain (If Applicable)

If you have a dishwasher, you need to connect its drain hose to the disposal. Locate the dishwasher inlet port on the side of the disposal—it’s usually a plastic or metal nipple. Remove the

knockout plug inside the port using a flathead screwdriver and a hammer. Be careful to knock the plug out without damaging the threads. Then, attach the dishwasher drain hose using a hose clamp. If your disposal doesn't have a built-in air gap, you can connect the hose directly. Check local plumbing codes; some areas require an air gap to prevent backflow.

Step 5: Wire the Electrical Connection

Most garbage disposals can be connected either by plugging into a wall outlet under the sink or by hardwiring directly. Check your local electrical code. For a plug-in installation, attach a power cord to the disposal's terminal block. Remove the cover plate, insert the cord through the strain relief, and connect the wires: black to black (hot), white to white (neutral), and green or bare to the ground screw. Tighten securely, replace the cover, and plug into a grounded outlet. For hardwiring, run the cable from the switch box to the disposal using wire nuts and appropriate connectors. Always double-check connections with a voltage tester before proceeding.

Step 6: Attach the Disposal to the Mounting Assembly

Lift the disposal unit and align its mounting ears with the tabs on the mounting ring. Rotate the unit clockwise until it locks into place. Some models require you to tighten a mounting bolt or ring further using a wrench or special tool provided. Ensure the disposal hangs level and is firmly attached. You should not be able to rotate it easily by hand.

Step 7: Connect the Plumbing

Reattach the drain pipes. Most installations involve connecting the disposal's discharge tube to the P-trap and then to the main drain line. Use the provided gaskets and slip nuts. For new installations, you may need to cut and assemble PVC pipes. Ensure all connections are hand-tight plus a quarter turn with a wrench. Do not overtighten, as this can crack the fittings. If you have a dishwasher, double-check the hose connection is secure and not kinked.

Step 8: Test for Leaks and Proper Operation

Before turning on the power, plug the sink and fill it halfway with

water. Then, unplug the sink and turn on the water. Look under the sink for any drips. Tighten connections if needed. Once you're satisfied that there are no leaks, turn the power back on at the breaker and flip the switch. You should hear a hum as the motor starts. Run cold water and feed a few small scraps, like citrus peels or ice cubes, to test the grinding action. The unit should run smoothly without excessive vibration or noise. If you hear rattling, check that the mounting is secure.

TROUBLESHOOTING COMMON INSTALLATION ISSUES

The Disposal Won't Turn On

If the unit doesn't power up, first check the breaker and the outlet. Press the reset button on the bottom of the disposal. If it still doesn't work, inspect the wiring for loose connections. Also, ensure the unit is properly mounted—some models have a safety switch that prevents operation if the mounting ring isn't engaged correctly.

Water Leaks at the Flange

Leaks around the sink flange usually indicate insufficient plumber's putty or a loose mounting ring. Remove the disposal, apply fresh putty, and retighten. For leaks at the dishwasher connection, check the hose clamp and ensure the knockout plug was fully removed.

Dishwasher Drains Slowly

If your dishwasher drains slowly after installation, the knockout plug might still be partially blocking the inlet. Disconnect the hose and use a screwdriver to fully remove any remaining plastic.

MAINTENANCE TIPS FOR YOUR NEW GARBAGE DISPOSAL

Proper care extends the life of your disposal. Always run cold water while grinding and for 30 seconds after to flush debris. Avoid putting fibrous foods (celery, corn husks), grease, or large bones down the unit. Once a week, grind ice cubes and coarse salt to clean the blades and remove odors. Never use chemical drain cleaners, as they can damage the disposal's seals.

CONCLUSION

Learning how to install a garbage disposal is a rewarding DIY project that modernizes your kitchen and simplifies cleanup. By following these steps—gathering the right tools, preparing the sink, connecting the mounting assembly, handling the electrical and plumbing connections, and testing thoroughly—you can complete the installation safely and efficiently. Remember to prioritize safety, take your time with each step, and don't hesitate to consult a professional if you encounter unexpected obstacles. With your new disposal in place, you'll wonder how you ever managed without it.